

Protec Covers

Swift Basecamp Jacket Fitting Guide



These fitting instructions are aimed as a guide to the best way that we've found to fit your Protec cover.

Before fitting, it is essential that the front of your caravan is clean and free of grit. If any grit or dirt becomes trapped between the cover and the caravan, there is a risk of scratching.

Towing Jackets are designed for towing purposes only; we do not advise that they are kept on the caravan for storage.

Contents

- Towing Jacket
- Storage Bag
- A-Frame Strap
- SNAD Fasteners

Fitting Instructions

1. Unpack your Towing Jacket and attach the enclosed SNAD fasteners to the press studs situated around the edge of the Towing Jacket.

2. Once the cover is in the correct position (lights are visible, and it fits nicely around the a-frame), remove the backing from the SNAD fasteners to reveal the adhesive backing.
3. Stick the SNAD fasteners firmly to the caravan. **TIP:** This step is only required the first time fitting the cover; the SNAD pads will stay on the caravan permanently, but if you do need to remove them, this can be done by levering a credit card-sized object underneath.
4. Attach the elasticated hooks to the underside of the caravan skirt.
5. Attach the a-frame strap to the two buckles located at each side of the tow hitch, passing it underneath the tow hitch assembly.

Towing Jacket Features

If you chose to have grab handle access, you will be able to access your handles by undoing the Velcro flaps situated on the cover.

For access to your window, undo the top few press studs from the SNAD fasteners.

To gain access to your locker, unfasten the elastic hooks and one side of the a-frame strap. Undo the cover from the SNAD Fasteners on the bottom and lift the cover.

Care Instructions

Clean the cover using warm water with a soft brush, a hosepipe may be used but we do not advise the use of power washers.

DO NOT use any detergents or chemicals, as this will block the pores and affect the hydrophobic properties of the fabric. However, if you have any stubborn stains that will not be removed with just warm water, you can add soap flakes (the type you would use to hand-wash clothing) to the warm water to aid the washing.